


## Accessories

### Memory Cassettes

The Loader functionality allows the memory cassette to upload and download programs from and to the internal memory of the FX main units. When the memory cassette is attached to the FX main unit without uploading or downloading, the program on the memory cassette is executed.




Model Number	FX3U-FLROM-16	FX3U-FLROM-64	FX3U-FLROM-164L	FX1N-EEPROM-8L	FX3G-EEPROM-32L
Stocked Item	S	S	S	S	S
Rating	CE (EMC)				
Size	16,000	64,000	64,000	2,000 / 8,000 steps	32,000 steps
Memory Type	Flash	Flash	Flash	EEPROM	EEPROM
Protect Switch	Provided	Provided	Provided	Provided	Provided
Data Transfer Buttons	Not Provided	Not Provided	Provided	Provided	Provided
Dimensions W x H x D (mm)	37 x 20 x 6.1	37 x 20 x 6.1	37 x 20 x 6.1	33 x 30 x 9	35 X 21 X 9.6
Applicable PLCs	FX3U / FX3UC			FX1S / FX1N	FX3G

### Backup Batteries

Backup batteries provide enough power to store relevant data within the FX main units and modules when they are not powered.

Model Number	FX3U-32BL	FX1N-BAT
Stocked Item	S	S
Applicable Main Units	FX3U / FX3UC	FX1N



### Interface Converter

Interface converter is necessary to bridge two different communication types.

Model Number	FX-USB-AW	FX-232AWC-H
Stocked Item	S	-
Rating	CE (EMC)	CE (EMC)
Applicable PLCs	FX1S/FX1N/FX3U/FX3UC/FX3G	FX1S/FX1N/FX3U/FX3UC/FX3G
Applications	USB to RS-422 converter	RS-422 to RS-232C converter
Dimensions (W x H x D) mm	14 x 20 x 63	25 x 80 x 60

