


FX3UC



Special Adapters

3

FX3U-4AD-ADP
FX3U-4AD-PNK-ADP

Analog	Temperature
FX3U-4AD-ADP FX3U-4DA-ADP FX3U-3A-ADP	FX3U-4AD-PT-ADP FX3U-4AD-TC-ADP FX3U-4AD-PTW-ADP FX3U-4AD-PNK-ADP

2

FX3U-232ADP-MB
FX3U-485ADP-MB

Communication
FX3U-232ADP-MB FX3U-485ADP-MB

FX3UC Main Units

1

FX3UC Main Units 16-96 I/O

FX3UC-16MT/D *	DC	D1	T1
FX3UC-16MT/DSS	DC	D2	T2
FX3UC-32MT/D *	DC	D1	T1
FX3UC-32MT/DSS	DC	D2	T2
FX3UC-64MT/D *	DC	D1	T1
FX3UC-64MT/DSS	DC	D2	T2
FX3UC-96MT/D *	DC	D1	T1
FX3UC-96MT/DSS	DC	D2	T2

DC DC Power supply
D1 DC Input(sink)
D2 DC Input(source)
T1 Transistor Output(sink)
T2 Transistor Output(source)

* Refer to the HARDWARE MANUAL for system configuration.

Special Function Modules*

* The special function Modules of FX3UC-*/MT/DSS.

4 I/O Extension Blocks

Input Extension Blocks
FX2NC-16EX-T-DS
FX2NC-16EX-DS
FX2NC-32EX-DS

Output Extension Blocks
FX2NC-16EYR-T-DS
FX2NC-16EYT-DSS
FX2NC-32EYT-DSS

6 Power Supply Unit

FX3UC-1PS-5V
FX2NC-CNV-IF

OR

Interface Converter

7 Unpowered extension Blocks

Input Extension Blocks
FX2N-8EX-ES/UL
FX2N-8EX-UA1/UL
FX2N-16EX-ES/UL

Output Extension Blocks
FX2N-8EYR-ES/UL
FX2N-8EYR-ESS/UL
FX2N-16EYR-ESS/UL
FX2N-16EYT-ESS/UL
FX2N-16EYS

5 Special Function Blocks

Analog
FX3UC-4AD
FX2NC-4AD

High Speed Counter
FX2NC-1HC

8 Network

FX2N-16CCL-M **FX3U-32DP**
FX2N-32CCL **FX3U-64DP-M**
FX3U-64CCL
FX3U-ENET

Temperature
FX2N-2LC

High Speed Counter
FX2N-1HC

Communication
FX2N-232IF

Optional Equipment and Software

GOT
GOT1000 (GT10/GT11/GT15)

Software
GX Developer

Interface Converters
FX-USB-AW
FX-232AWC-H

Accessories

Memory Cassettes
FX3U-FLROM-64
FX3U-FLROM-16
FX3U-FLROM-64L

I/O Cables
General I/O cable
FX-16E-500CAB-S(5m)

Connecting to Terminal Block
FX-16E-150CAB(1.5m) FX-16E-150CAB-R(1.5m)
FX-16E-300CAB(3m) FX-16E-300CAB-R(3m)
FX-16E-500CAB(5m) FX-16E-500CAB-R(5m)

Connector Parts
FX2C-I/O-COON
FX2C-I/O-COON-S
FX2C-I/O-COON-SA

Terminal Blocks
FX-16E-TB/UL
FX-16EYR-ES-TB/UL
FX-16EYS-ES-TB/UL
FX-16EYT-ESS-TB/UL
FX-32E-TB/UL

Input Switches
FX2C-16SW-C
FX2C-16SW-TB

Battery
FX3U-32BL

Extension Cables
FX3N-30EC(30cm)
FX3N-65EC(65cm)

PLC Bus Connector
FX3N-CNV-BC

Power Supply Cables
FX3NC-100MPCB(1m)
FX3NC-100BPCB(1m)
FX3NC-100BPCB1(0.1m)